



DOLLY DIGITAL®



# Dolly Digital® FD-Pro

## Charging:

- Make sure the headphones are charged using the supplied USB cable
- Check the battery level by briefly pressing the volume button – the green LED lights on the side of the headphones will indicate the charge

## Playback:

- Connect the transmitter to your audio source via Bluetooth or cable
- Turn on the headphones by pressing the Power button – the headphones will automatically connect to the transmitter
- Change the channel by briefly pressing the Power button
- Adjust the volume using the volume button on the headphones

**Tip:** To turn off the LED lighting, press and hold the volume or LED button for 2 seconds

[dolly-digital.com](http://dolly-digital.com)

