

Dolly Digital® RD-PRO

Charging:

Ensure the headphones are charged using the supplied USB cable.

Playback:

- Connect the transmitter to your audio source via Bluetooth or cable.
- Turn on the headphones by pressing the Power button – the headphones will automatically connect to the transmitter.
- Change the channel by briefly pressing the Power button.
- Adjust the volume using the volume button on the headphones.

Tip: To turn off the LED lighting, press and hold the volume or LED button for 2 seconds.







